



DOLBY VOICE[®] CAMERA PRO

QUICK START GUIDE


Dolby Voice Room Pro



CAMERA



HUB



PHONE



USB 1

HUB TO CAMERA



USB 2

HUB TO CAMERA



POWER

CAMERA TO WALL



DISPLAY CABLE

HUB TO DISPLAY



POWER

HUB TO WALL



ETHERNET - 9'

HUB TO NETWORK




ETHERNET - 25'

HUB TO PHONE


Overview

QUICK START


PERIPHERALS / OPTIONAL MODES




Wall Mount




View Angle



Position Above TV



Position Below TV



 **DOLBY VOICE**[®]